

Assemble poles first

by inserting poles with inner sleeves into the poles with velcro attached.

Fit the poles into the wooden bases, ensuring that the velcro is facing towards the front and rear of the display, with the velcro going over the top of the pole.

Remove liner from pressure sensitive adhesive strips/velcro

Lower scoreboard (print side out) down onto poles - press to secure.